

## 2. Troubleshooting

### 2.1 Display board


2.1.1 Icon explanation on indoor display board (Super slim cassette 24K~48K).




2.1.2 Icon explanation on indoor display board (Compact cassette 12K~18K).




2.1.3 Icon explanation on indoor display board (Ceiling & Floor, 12K~18K)




2.1.4 Icon explanation on indoor display board (Ceiling & Floor, 24K~48K)



### 2.1.5 Icon explanation on indoor display board (A5 Duct)



### 2.1.6 Icon explanation on indoor display board (Console)



### 2.1.7 Display board of auto-lifting panel of 4 way cassette (24K~48K)



122

### 2.2 Indoor unit malfunction

### For Console

NO.	Malfunction	Running lamp	Timer lamp	Defrosting lamp
1	Open or short circuit of T1 temperature sensor	☆	Х	X
2	Open or short circuit of T2 temperature sensor	Х	Х	☆
3	Communication malfunction between indoor and outdoor units.	Х	*	Х
4	Outdoor fan speed has been out of control	X	☆	0
5	Indoor EEPROM malfunction	☆	☆	X
6	IPM module protection	☆	Х	☆
7	Open or short circuit of T3 or T4 temperature sensor or Outdoor unit EEPROM parameter error	☆	☆	¥
8	Over voltage or over low voltage protection	☆	☆	0
9	Top temperature protection of compressor	☆	0	X
10	Inverter compressor drive protection	☆	0	Х
11	Indoor fan Speed has been out of control.	☆	0	☆
	O(light) X(off) ☆(flash at 5Hz)	©(flash at 0.5Hz)		

For 12K & 18K units(excluding console)

NO.	Malfunction	Running lamp	Timer lamp	Defrosting lamp	Alarm lamp	Display(nixie tube)
1	Open or short circuit of T1 temperature sensor	☆	Х	Х	Х	E0
2	Open or short circuit of T2 temperature sensor	Х	Х	☆	Х	E1
3	Communication malfunction between indoor and outdoor units.	Х	☆	Х	Х	E2
4	Water-level alarm malfunction	Х	Х	Х	☆	E3
5	Indoor EEPROM malfunction	☆	☆	Х	Х	E4
6	IPM module protection	☆	Х	Х	0	E5
7	Open or short circuit of T3 or T4 temperature sensor or outdoor EEPROM is malfunction	☆	0	Х	Х	E6
8	Outdoor fan speed has been out of control	☆	0	☆	Х	E7
9	Refrigerant Leakage Detection	0	Х	☆	☆	EC
10	Communication malfunction between main PCB and up-down panel PCB	☆	Х	☆	☆	F0
11	Up-down panel malfunction	X	☆	☆	☆	F1
12	Indoor fan speed has been out of control	☆	0	0	Х	F5
13	Outdoor unit voltage protection	☆	0	Х	0	P0
14	Compressor top temperature protection	☆	Х	0	Х	P1
15	Outdoor unit over-current protection	☆	☆	☆	Х	P2
16	Inverter compressor drive error	☆	0	Х	Х	P4
14	Compressor top temperature protection  Outdoor unit over-current protection	\$ \$	X	O A	X	

O(light) X(off)  $\not\simeq$  (flash at 2.5Hz)  $\bigcirc$  (flash at 0.5Hz) F0,F1 is only available for super-slim cassette

# 2.3 Outdoor unit malfunction For KSIL012-H219-OC, KSIO012-H223-OC, KSIL018-H220-OC, KSIO018-H221-OC:

No.	Problems	Green	Red	IU display
1	standby for normal	0	Х	
2	Operation normally	х	0	
3	IPM malfunction or IGBT over-strong current protection	☆	x	P0
4	Over voltage or too low voltage protection	0	0	P1
5	Inverter compressor drive error	х	☆	P4
6	Inverter compressor drive error	☆	0	P4
7	Communication malfunction between compressor driver board and outdoor main board	☆	☆	P4
8	Compressor driver board EEPROM malfunction	0	☆	E5

### For other models:


Display	Malfunction or Protection
E0	Outdoor EEPROM malfunction
E2	Communication malfunction between indoor and outdoor units
E3	Communication malfunction between IPM board and outdoor main board
E4	Open or short circuit of outdoor temperature sensors
E5	Voltage protection of compressor
E8	Outdoor fan speed has been out of control
P0	Top temperature protection of compressor
P1	High pressure protection(For 36K-48K)
P2	Low pressure protection(For 36K-48K)
P3	Current protection of compressor
P4	Discharge temperature protection of compressor
P5	High temperature protection of condenser
P6	IPM module protection
P7	High temperature protection of evaporator

In low ambient cooling mode, the LED displays "LC" or alternative displays between running frequency and "LC"(each displays 0.5s)


### 2.4 Solving steps for typical malfunction

### 2.4.1 For the indoor unit


### 2.4.1.1 Open or short circuit of temperature sensor



### 2.4.1.2. Outdoor unit malfunction




### 2.4.1.3. Indoor EEPROM malfunction




EEPROM: An electrically erasable programmable read-only memory whose contents can be erased and reprogrammed using a pulsed voltage.

### 2.4.1.4. Water-level alarm malfunction




2.4.1.5.Communication malfunction between indoor and outdoor units The same as E2 in outdoor.

### 2.4.1.5. Indoor fan Speed has been out of control. (Only for the units used DC motor)




### DC motor voltage input and output (control chip is inside the motor)



DC motor voltage input and output

NO.	Color	Signal	Voltage
1	Red	Vs/Vm	200~380V
2			
3	Black	GND	0V
4	White	Vcc	13.5~16.5V
5	Yellow	Vsp	0~6.5V
6	Blue	FG	13.5~16.5V

### 2.4.1.6. Refrigerant Leakage Detection




### 2.4.1.7. Inverter compressor drive protection

Refer to the outdoor unit P6 malfunction part to solve this problem.

# **2.4.1.8 Communication malfunction between indoor and outdoor units** The same as E2 in outdoor.


### 2.4.2 For the super-slim cassette with up-down panel

### 2.4.2.1 Communication error between indoor unit and up-down panel




### 2.4.4 For the outdoor unit


### 2.4.4.2. E0 malfunction




EEPROM: An electrically erasable programmable read-only memory whose contents can be erased and reprogrammed using a pulsed voltage.


### 2.4.4.3. E2 malfunction(For 12-18K units):








# 2.4.4.6. E4 malfunction E4 display Judge 1: Outdoor condenser temp. sensor (T3) is malfunction Check whether the wiring of the Connect the wiring well condenser temp. sensor(T3) is broken off No Check whether the resistance of condenser temp. sensorT3) is wrong Replace condenser temp. sensor(T3) refer to the Appendix 1 No Judge 2: Outdoor ambient temp. sensor (T4) is malfunction Check whether the wiring of the Connect the wiring well outdoor ambient temperature sensor (T4) is broken off Νo Check whether the resistance of outdoor ambient temperature Replace outdoor ambient sensor (T4) is wrong refer to the temperature sensor (T4) Appendix 1 No Judge 3: Compressor discharge temp. sensor (T5) is malfunction Check whether the wiring of the compressor discharge temperature Connect the wiring well sensor (T5) is broken off No Check whether the resistance of Replace compressor discharge compressor discharge temp. sensor temperature sensor (T5) (T5) is wrong refer to the Appendix 2 No Replace outdoor main PCB





# 2.4.4.8. E8 malfunction The same as E8 in indoor.

### 2.4.4.9. P0 malfunction



### 2.4.4.10. P1 malfunction (Only for 36K~48K)






#### 2.4.4.12. P3 malfunction P3 display Current protection of compressor The protection occurred in standby Νo Yes Check whether the power Restart the unit when the power voltage is normal. supply gets normal Yes Check the wiring of Measure whether outdoor power wires well or Reconnect it well terminal voltage is normal? correctly Yes Check the wiring of Measure whether the voltage Reconnect it well L and N well or between L and N is normal? correctly Yes Check the wiring of Measure whether input voltage bridge rectifier well or correctly Reconnect it well of bridge rectifier is normal? Yes Measure whether the Replace the outdoor main PCB current is normal? No Measure whether the voltage Check whether Replace the bridge between P and N is normal bridge rectifier is rectifier refer to the Appendix 3? normal Yes Yes Check whether the outdoor Replace the PFC module(If has) ambient temperature is Stop the unit higher than $50\,^\circ\!\mathbb{C}$ No Νo Check the wiring of Reconnect the reactor or inductance wiring Check if the outdoor unit Make the outdoor unit ventilate well ventilation is good Yes Yes please refer to the solution of fan speed has been out of control Check if the outdoor fan malfunction . Find out the cause and Check whether reactor Replace reactor or runs properly have it solved. or inductance is normal inductance Yes Check whether the heat Clean the heat exchanger exchanger is dirty No Replace outdoor main board No Check whether system pressure Recycle the over charged is too high refrigerant No Check whether the refrigerant system is ok


### 2.4.4.13. P4 malfunction

When compressor discharge temperature is higher than 115°C, the unit will stop, and unit runs again when compressor discharge temperature is lower than 90°C.




### 2.4.4.14. P5 malfunction

When condenser high temp. is more than 65°C, the unit will stop, and unit runs again when outdoor pipe temp. less than 52°C.



### 2.4.4.15. P6 malfunction

At first test the resistance between every two ports of U, V, W of IPM and P, N. If any result of them is 0 or close to 0, the IPM is defective. Otherwise, please follow the procedure below:



Replace the indoor main

### 2.4.4.16. P7 malfunction P7 display High temperature protection of evaporator Check the connection Whether compressor between T2 and PCB. Correct the connection operates? Check whether T2 and T2B Is reversed Yes Yes Check whether the outdoor ambient temperature is higher Stop the unit than $30^{\circ}\!\mathbb{C}$ Check whether the resistance of T2 is normal Νo Replace the temperature sensor refer to the Appendix 1 Check whether the air-outlet is Clean the air-outlet blocked? No please refer to the solution of fan speed has been out of control Check whether the indoor fan is running normal? malfunction. Find out the cause and have it solved. Yes Check whether the heat exchanger and filter are Clean the heat exchanger and filter dirty?

Yes

**Appendix** 1 Temperature Sensor Resistance Value Table (°C--K)

Appendix	Appendix 1 Temperature Sensor Resistance Value Table (°CK)									
°C	K Ohm	${\mathfrak C}$	K Ohm	ဗ	K Ohm	${\mathfrak C}$	K Ohm			
-20	115.266	20	12.6431	60	2.35774	100	0.62973			
-19	108.146	21	12.0561	61	2.27249	101	0.61148			
-18	101.517	22	11.5000	62	2.19073	102	0.59386			
-17	96.3423	23	10.9731	63	2.11241	103	0.57683			
-16	89.5865	24	10.4736	64	2.03732	104	0.56038			
-15	84.2190	25	10.000	65	1.96532	105	0.54448			
-14	79.3110	26	9.55074	66	1.89627	106	0.52912			
-13	74.5360	27	9.12445	67	1.83003	107	0.51426			
-12	70.1698	28	8.71983	68	1.76647	108	0.49989			
-11	66.0898	29	8.33566	69	1.70547	109	0.48600			
-10	62.2756	30	7.97078	70	1.64691	110	0.47256			
-9	58.7079	31	7.62411	71	1.59068	111	0.45957			
-8	56.3694	32	7.29464	72	1.53668	112	0.44699			
-7	52.2438	33	6.98142	73	1.48481	113	0.43482			
-6	49.3161	34	6.68355	74	1.43498	114	0.42304			
-5	46.5725	35	6.40021	75	1.38703	115	0.41164			
-4	44.0000	36	6.13059	76	1.34105	116	0.40060			
-3	41.5878	37	5.87359	77	1.29078	117	0.38991			
-2	39.8239	38	5.62961	78	1.25423	118	0.37956			
-1	37.1988	39	5.39689	79	1.21330	119	0.36954			
0	35.2024	40	5.17519	80	1.17393	120	0.35982			
1	33.3269	41	4.96392	81	1.13604	121	0.35042			
2	31.5635	42	4.76253	82	1.09958	122	0.3413			
3	29.9058	43	4.57050	83	1.06448	123	0.33246			
4	28.3459	44	4.38736	84	1.03069	124	0.32390			
5	26.8778	45	4.21263	85	0.99815	125	0.31559			
6	25.4954	46	4.04589	86	0.96681	126	0.30754			
7	24.1932	47	3.88673	87	0.93662	127	0.29974			
8	22.5662	48	3.73476	88	0.90753	128	0.29216			
9	21.8094	49	3.58962	89	0.87950	129	0.28482			
10	20.7184	50	3.45097	90	0.85248	130	0.27770			
11	19.6891	51	3.31847	91	0.82643	131	0.27078			
12	18.7177	52	3.19183	92	0.80132	132	0.26408			
13	17.8005	53	3.07075	93	0.77709	133	0.25757			
14	16.9341	54	2.95896	94	0.75373	134	0.25125			
15	16.1156	55	2.84421	95	0.73119	135	0.24512			
16	15.3418	56	2.73823	96	0.70944	136	0.23916			
17	14.6181	57	2.63682	97	0.68844	137	0.23338			
18	13.9180	58	2.53973	98	0.66818	138	0.22776			
19	13.2631	59	2.44677	99	0.64862	139	0.22231			

**Appendix 2** 

	U	Init: ℃K		Discharge	temp. sensor tabl	е	
-20	542.7	20	68.66	60	13.59	100	3.702
-19	511.9	21	65.62	61	13.11	101	3.595
-18	483	22	62.73	62	12.65	102	3.492
-17	455.9	23	59.98	63	12.21	103	3.392
-16	430.5	24	57.37	64	11.79	104	3.296
-15	406.7	25	54.89	65	11.38	105	3.203
-14	384.3	26	52.53	66	10.99	106	3.113
-13	363.3	27	50.28	67	10.61	107	3.025
-12	343.6	28	48.14	68	10.25	108	2.941
-11	325.1	29	46.11	69	9.902	109	2.86
-10	307.7	30	44.17	70	9.569	110	2.781
-9	291.3	31	42.33	71	9.248	111	2.704
-8	275.9	32	40.57	72	8.94	112	2.63
-7	261.4	33	38.89	73	8.643	113	2.559
-6	247.8	34	37.3	74	8.358	114	2.489
-5	234.9	35	35.78	75	8.084	115	2.422
-4	222.8	36	34.32	76	7.82	116	2.357
-3	211.4	37	32.94	77	7.566	117	2.294
-2	200.7	38	31.62	78	7.321	118	2.233
-1	190.5	39	30.36	79	7.086	119	2.174
0	180.9	40	29.15	80	6.859	120	2.117
1	171.9	41	28	81	6.641	121	2.061
2	163.3	42	26.9	82	6.43	122	2.007
3	155.2	43	25.86	83	6.228	123	1.955
4	147.6	44	24.85	84	6.033	124	1.905
5	140.4	45	23.89	85	5.844	125	1.856
6	133.5	46	22.89	86	5.663	126	1.808
7	127.1	47	22.1	87	5.488	127	1.762
8	121	48	21.26	88	5.32	128	1.717
9	115.2	49	20.46	89	5.157	129	1.674
10	109.8	50	19.69	90	5	130	1.632
11	104.6	51	18.96	91	4.849		
12	99.69	52	18.26	92	4.703		
13	95.05	53	17.58	93	4.562		
14	90.66	54	16.94	94	4.426		
15	86.49	55	16.32	95	4.294	B(25/50	)=3950K
16	82.54	56	15.73	96	4.167		
17	78.79	57	15.16	97	4.045	R(90°C)=	=5KΩ±3%
18	75.24	58	14.62	98	3.927		
19	71.86	59	14.09	99	3.812		

### Appendix 3

Normal voltage of P and N										
208	380-420V(3-phase)									
In standby										
	around 530VDC									
In operation										
With passive PFC	/									
module	/									
>200VDC	>310VDC	>370VDC	>450VDC							

# Appendix 4:

°C	10	11	12	13	14	15	16	17	18	19	20	21	22
°F	48	50	52	54	56	58	60	62	64	66	68	70	72
°C	23	24	25	26	27	28	29	30	31	32	33	34	35
°F	74	76	78	80	82	84	86	88	90	92	94	96	98



The Klimaire logo is a registered Trademark of Klimaire Products inc.

Copyright 2016 Klimaire Products Inc.

2190 NW 89 Place, Doral, FL 33172 - USA

Tel: (305) 593-8358 Fax (305) 499-4378

www.klimaire.com sales@klimaire.com